



Progressive Dynamics, Inc.

The Source of Bright Ideas Since 1961

INTELI-POWER 9200™ SERIES

Truck Converter/Charger with built-in CHARGE WIZARD®

INTELI-POWER 9200 SERIES model can recharge the battery to 90% in 2-3 hours using our patented CHARGE WIZARD technology.

The built-in CHARGE WIZARD automatically selects one of four operating modes: BOOST, NORMAL, STORAGE, DESULFATION.

BOOST Mode 14.4 Volts -Rapidly brings RV battery up to 90% of full charge.

NORMAL Mode 13.6 Volts - Safely completes the charge.

STORAGE Mode 13.2 Volts -Maintains charge with minimal gassing or water loss.

DESULFATION Mode 14.4 Volts- Every 21 hours for a period of 15 minutes to prevent battery stratification.



Remote pendant included with every retail unit.



Covered by one or more of the following patents: 5,600,550, 5,687,066, 5,982,643, 6,184,649.



Built-in CHARGE WIZARD®
constantly monitors voltage status and automatically manages your battery.

BT1-3511

70 AMP PD9270V

Input: 105-130 VAC

Output: 13.6 VDC

Dimensions: 3.6"H x 8"L x 9"W

Weight: 5.8 lbs



With features such as reverse battery protection, filtered DC power, electronic current limiting, low line voltage protection, intelligent cooling fan, and more, the BT1-3511 70 Amp Converter/Charger with built-in Charge Wizard will maintain your truck battery for longer life.

Distributed By: